

Flowtex HT

Application instructions

Preparation/Substrate

Surfaces to be coated should be sound and provide adequate strength for the proposed end use with a minimum compressive strength of 25 N/mm². Check the relative humidity of floors at ground level. Substrate humidity must not exceed 75% RH (otherwise the primer must be substituted with Hydraseal DPM).

Blasting, scarifying or diamond grinding removes laitance. Irregularities, damage and cracks can be filled with epoxy screed (e.g. Flowtex F1 Mortar) or levelled with an epoxy scratch-coat (e.g. Flowprime mixed with fine dry sand).

All mobile joints must pass through the screed and must be sealed tight. Anchor grooves must be cut on both sides of such joints. Welded joints and cracks in the concrete may be coated, but if movement occurs the screed will also crack.

All residues must be removed to provide a dry, dust free open textured surface. The surface profile and levels should be appropriate for the system to be applied.

Contact us for advice if there are impurities, such as oils etc., in the concrete.
Follow our instructions for connections to grid drains, cesspools, pipes and pipe inlets.

Primer

Prime using **Flowprime**.

Pour Hardener B into the packaging holding Base A and completely pour out the resultant mixture. Mix using a low-speed drill and stirrer until a homogenous mixture is obtained. Do not mix in too much air.

Natural quartz 0.7-1.2 mm (**B&E 1.1**) or similar is sprinkled in the wet primer. Allow the primer to harden until the surface can be walked on, approx. 15 hours at 20°C. At lower temperatures the hardening time is longer.

Apply immediately after mixing using a double-lipped rubber rake and/or roller. Ensure that the primer permeates any surface irregularities.

Consumption, primer: approx. 0.3 kg/m².

Hydraseal DPM is to be used as the primer in instances where the substrate is damp; refer to a separate application instruction for more information.

Mixing

Flowtex is supplied in complete batches, A+B+C. Add the Hardener to Base A and mix thoroughly for 1-2 minutes using drill and helical spinner. Transfer to a rotary forced action mixer and add the Filler C and mix for a further 2 minutes until uniform. The mixed material should be used immediately for best results and within 20 minutes.

Remember never to split batches/components. Incorrect mixing ratios or poor mixing can result in irregular hardening or variations in colour, etc.

Application

The ready-mixed compound is poured into a laying box and the box weighted. The box is then drawn at an even speed over the surface to be laid. After each run it is compacted and smoothed with a steel trowel by hand or power float.

Finishing with a smoothing machine should be carried out after two runs have been laid closing the sledge marks by hand before doing this.

Alternately Flowtex HT may be spread and applied by hand towelling. In this case 5mm screed bars should be used to accurately gauge the thickness of the applied product. Once spread to the desired thickness. Compact and finish with a steel trowel.

NOTE! Do not smooth closer to the edge than approx. 15 cm, i.e. the edge between the concrete and in to the laid compound, this is to ensure the next mix can be correctly blended in with the last.

Skirting/coves

To achieve the best results the floor, coves and skirting should be applied in a single procedure. If procedures are carried out before or after there will be a visible seam between the floor and cove. Check if the skirting should follow the floor, or be straight in the top edge. Limit the height with tape or a fixed edge trim before starting, and then prime the wall with Flowprime.

Apply the skirting compound in the wet primer with a coving trowel trowel, Carefully smooth. If applied to a tape, draw the tape and brush to the top edge to obtain a smooth transition.

NOTE! Pay special attention to the above. A well executed skirting shows good workmanship.

Topcoats

Before applying topcoat the skirting, coves and floor should be scraped to remove all loose stones and high points. The surfaces should then be thoroughly vacuum cleaned. The compound should harden for at least 15 hours before applying the topcoat.

Apply a flood layer of FLOWSEAL on the Flowtex surface. Allow the topcoat to penetrate down into the compound for approx. 5 minutes, then smooth the surface with a broad spatula or foam squeegee. Finally, smooth the surface with a rubber squeegee and roll with medium pile to obtain a consistent surface structure.

Second Topcoat

Apply a further coat of FLOWSEAL in the same way as the first coat, less penetration time should be required for the second coat. If a slight texture is required care must be taken to keep the final coat very tight!

Do not mix overlarge batches of topcoat. If the topcoat starts to harden during the application this will result in an uneven structure. Do not mix more than can be used within 20 minutes.

Optional matt sealer

Apply an additional layer of SUPERSATIN using short mohair or medium pile type rollers of high quality i.e. "no fluff" type, always apply using a paint tray. Ensure that no fluff is expelled from the roller.

NOTE! It is essential that this coating be applied at the correct film thickness. Thick film builds may result in surface imperfections. Always use a paint tray when sealing. Do NOT tip into pools on the floor.

Note that :

Flowcrete products are often multiple-component systems. Poor mixing, or incorrect mixing procedures, can result in irregular and incomplete hardening, which in turn can result in an inferior final result. Check that all pack sizes and colours correspond to the floor area being installed.

Flowcrete SA (Pty) Ltd is a subsidiary of Flowcrete Group plc
176 Voortrekker Street
Jacobs
Durban
Kwa Zulu Natal
Tel: +27 31 461 3411
Fax: +27 31 461 3475
Email: southafrica@flowcrete.com

www.flowcretesa.co.za

The temperature should be over 15°C to achieve the best results during application. The temperature of the substrate should be at least 10°C, although a temperature of 15-25°C is recommended.

The temperature of the substrate should exceed the “dew point” by more than 3°C during application and hardening.

The product should be stored in such a way that the temperature is the same as the room temperature where the product is to be applied, i.e. between 15-25°C. This improves the mixing, flow, penetration and hardening of the product.

The surface can normally be walked on after approx. 15 hours at 20°C. Complete hardening takes 5-7 days.

There are often several types of products at a workplace. Sort the products separately to avoid mistakes.

Consumption

Consumption of flooring Materials

Primer	Flowprime	0.3 kg/m ² (Depends on porosity of substrate)
Aggregate scatter	0.7-1.2mm quartz	0.5 kg/ m ²
Screed compound		at 5 mm
Screed	Flowtex HT	10 kg/ m ²
Topcoat 1 ST coat	Flowseal	0.3 kg/ m ²
Topcoat 2 nd coat	Flowseal	0.3 kg/ m ²
Topcoat (Optional)	Supersatin	0.1 kg/ m ²

Ratio of Components

	weight	volume
Flowprime	2.3:1	2:1
Flowseal	2.2:1	2:1

Cleaning of Tools

Cleaned immediately after use in solvent, e.g. W.S.B.C or Acetone.

Any recommendation or suggestion relating to the use of the products made by Flowcrete UK Ltd., whether in its technical literature, or in response to a specific enquiry, or otherwise, is based upon data believed to be reliable, however the products and information are intended for use by Customers having requisite skill and know-how in the industry and therefore it is for the Customer to satisfy itself of the suitability of the products for its own particular use and it shall be deemed that the Customer has done so at its sole discretion and risk.

Durban

176 Voortrekker Street
Jacobs
Durban
Kwa Zulu Natal
Tel: +27 31 461 3411
Fax: +27 31 461 3475
Email: southafrica@flowcrete.com
Flowcrete SA (Pty) Ltd is a subsidiary of Flowcrete Group plc

Johannesburg

47 Forge Road
Spartan
Gauteng
Tel: +27 11 394 1980
Fax: +27 11 394 3003

Cape Town

1A Gabriel place
Cnr Gabriel & Main Road
Plumstead
Cape Town
Tel: +27 21 797 0214
Fax : +27 21 761 6664