



Your Guide to Flowcrete's DIY Floor Epoxy



www.flowcretesa.co.za

WHAT IS DIY EPOXYFLOR?

DIY EPOXYFLOR is Flowcrete's brand new, easy to apply, two part epoxy based floor system designed for use in a variety of domestic applications.

DIY EPOXYFLOR BENEFITS...



EASY, DIY APPLICATION



VARIETY OF APPLICATIONS



SUITABLE FOR SMALL JOBS



BRUSH & ROLLER APPLIED



READY TO USE IN 8-12 HOURS

Broom / Vacuum



Мор



TOOLS REQUIRED

STEP 1

STEP 2

Sweep floor to remove any dust.

Wash floor to remove any oils and contamination.





INSTRUCTIONS FOR USE

PLFASE NOTE ...

These instructions are for guidance only. The integrity of the final floor coating is the sole responsibility of the installer and Flowcrete can not be held responsible for incorrect application.

Grinder



Mohair Roller



STEP 3

Grind floor to create an open porous, lightly textured finish.



STEP 4

Vacuum or resweep floor.





Paint Tray



STEP 5

Mechanically mix Part B for 1 minute. Then mix part A and B for 3 minutes.



STEP 6


Apply 2–3 coats with brush and roller. Allow 6–8 hours between coats.



WHY CHOOSE **FLOWCRETE** PRODUCTS?

Flowcrete has over 30 years of experience in manufacturing specialist flooring materials for a wide range of commercial and industrial applications.

With manufacturing, warehousing and sales locations in South Africa and Kenya, as well as the support of a global network of offices spanning five continents, Flowcrete Africa is well placed to support customers across the African continent.















ww.flowcretesa.co.za