



Flowcoat SF41

Application instructions

Preparation/Substrate

Surfaces to be coated should be sound and provide adequate strength for the proposed end use (minimum 25 N/mm² compressive strength).

The surface profile and levels should be appropriate for the system to be applied. Substrate humidity must not exceed 75% RH, in which case use Hydraseal DPM.

Blasting, scouring or diamond grinding removes laitance. Irregularities, damage and cracks are filled with epoxy filler. All residues must be removed to provide a dry, dust free open textured surface.

Contact us for advice if there are impurities, such as oils etc., in the concrete. Check the relative humidity of floors at ground level. Follow our instructions for connections to grid drains, cesspools, pipes and pipe inlets.

Primer

Application on an untreated, porous concrete surface can cause air bubbles in the finished coating. To avoid this, prime the floor using an additional coat of Flowcoat SF41 naturals or Flowprime.

Pour Hardener B into the packaging holding Base A and completely pour out the resultant mixture. Mix using a low-speed drill and stirrer until a homogenous mixture is obtained (approximate mixing time – 3 minutes). Do not mix in too much air.

Allow the primer to harden until the surface can be walked on, approximately 15 hours at 20°C. At lower temperatures the hardening time is longer. It is important that there are no dry patches. If in doubt, check the adhesion using an adhesion tester. Minimum requirement is 1.5 MPa (1.8 MPa for heavy stress).

Apply immediately after mixing using a double-lipped rubber squeegee and/or roller. Ensure that the primer permeates any surface irregularities.

Consumption of primer: approximately 4m²/Litre.

Hydraseal DPM is to be used as the primer in instances where the substrate exceeds 75% RH; refer to the separate application instruction for more information.

Mixing

Flowcoat SF41 is supplied in complete batches, Base A and Hardener B. The coloured Base A must be stirred well. Transfer Hardener B to Base A. Mix thoroughly using a low-speed drill for 2-3 minutes. Thoroughly stir. The mixed material should be used within 20 minutes at 20°C.

Remember never to split batches/components. Incorrect mixing ratios or poor mixing can result in irregular hardening or variations in colour, etc.



Cleaning of Tools

Clean immediately after use in solvent, e.g. Flowsolve Cleaner or Acetone.

Any recommendation or suggestion relating to the use of the products made by Flowcrete SA, whether in its technical literature, or in response to a specific enquiry, or otherwise, is based upon data believed to be reliable, however the products and information are intended for use by Customers having requisite skill and know-how in the industry and therefore it is for the Customer to satisfy itself of the suitability of the products for its own particular use and it shall be deemed that the Customer has done so at its sole discretion and risk.

2015.07.08 South Africa