



# TAMMS THIN PATCH

## POLYMER-MODIFIED, MULTI-USE REPAIR MORTAR

HORIZONTAL REPAIR

TAMMS THIN PATCH

MASTER FORMAT #:  
09 09 09

### DESCRIPTION

TAMMS THIN PATCH is a polymer-modified, cement based mortar formulated for repairing defects in concrete and masonry surfaces from featheredge up to 2.54 cm.

### PRIMARY APPLICATIONS

- Horizontal, vertical or overhead repairs areas
- Interior and exterior use
- Repoint mortar joints
- Fill small holes, honeycomb and spalled

### FEATURES / BENEFITS

- Single-component
- Outstanding bond strength
- Trowelable repair mortar
- Long-term durability

### TECHNICAL INFORMATION

#### Material Properties @ 24°C

#### Set Times ASTM C 266

Initial set.....approx. 30 to 50 min

Final set.....approx. 1 to 2 hr

#### Compressive Strength MPa ASTM C 109

1 day.....8.3

28 day.....24.1

#### Split Tensile Strength MPa ASTM C 496

7 day.....1.4

28 day.....2.0.

#### Flexural Strength MPa ASTM C 348

7 day.....4.3

28 day.....5.0

#### Shrinkage % ASTM C 157 (3"x3"x11" specimens removed from molds @ 24 hours)

7 day.....-0.008%

28 days.....-0.040%

#### Scaling Resistance ASTM C 672

50 cycles.....0% loss

### SHELF LIFE

1 year in original, unopened package.

### PACKAGING

TAMMS THIN PATCH is packaged in 25kg bags

### COVERAGE/YIELD

A 25kg bag of TAMMS THIN PATCH will yield approximately 11L of material.

Applied at the following thicknesses, one 25kg bag of TAMMS THIN PATCH will cover:

6.3 mm	1.75m <sup>2</sup>
12.7 mm	0.87m <sup>2</sup>
25.4 mm	0.43m <sup>2</sup>

Note: Coverage rates are approximate and are for estimating purposes only

## DIRECTIONS FOR USE

---

**Surface Preparation:** Concrete surfaces must be structurally sound, free of loose or deteriorated concrete and free of dust, dirt, paint, efflorescence, oil and all other contaminants. Mechanically abrade the surface to achieve a surface profile of CSP 4 or greater in accordance with ICRI Guideline 310.2. Properly clean profiled area. Priming: Clean and prime exposed steel with DURALPREP A.C.. Concrete should be primed with a spray or brush coat of DURALPREP A.C.. The primer coat of DURALPREP A.C. must be allowed to thoroughly dry prior to the application of the repair mortar. Alternatively, a Saturated Surface Dry (SSD) concrete surface can be primed with a scrub coat of TAMMS THIN PATCH. The repair must be made before the scrub coat dries out.

**Mixing:** One 25kg bag of TAMMS THIN PATCH will require 3.4 to 3.6L of potable water.

Mix TAMMS THIN PATCH in a clean container using a slow speed drill and mixing blade. Pour potable water into the clean container and then gradually add the TAMMS THIN PATCH. Mix thoroughly to disperse all ingredients and to achieve a trowelable consistency. Do not use excess water, and do not retemper TAMMS THIN PATCH

**Application:** Apply sufficient pressure to fill all holes and voids, then trowel to a smooth finish. On large areas, use a screed to obtain a uniform level before troweling. Do not over-trowel. TAMMS THIN PATCH will achieve initial set in approximately 40 minutes; final set in approximately 1 hour, and cures within 24 hours under normal drying conditions. Maximum thickness of application is 25mm per lift. When applying multiple lifts, allow prior lift to reach final set, score the surface then place the subsequent lift.

## CLEAN UP

---

Clean all mixing and application equipment with water immediately following use. If material is allowed to dry on a surface, removal becomes extremely difficult.

## PRECAUTIONS / LIMITATIONS

---

- Do not apply to frozen or frost filled surfaces, at temperatures below 4°C or if temperature is expected to fall below 4°C within 24 hours.
- Application temperatures below 16°C will extend set time.
- On windy or hot days or for application in direct sunlight, use wet burlap or plastic sheet for curing.
- Do not use TAMMS THIN PATCH in joints or cracks that are subject to movement.
- Do not apply TAMMS THIN PATCH in more than 25 mm deep lifts.
- Do not over-work or over-trowel the repair.
- Do not add more water than recommended.
- Protect from rain for 24 hours after placement.
- In all cases, consult the Safety Data Sheet before use

Rev: 16/02/17